

OBR ADV Gear Grip Mitt Installation Instructions

Congratulations on your OBR ADV Gear Grip Mitt purchase. Your OBR ADV Gear Grip Mitts have been designed to fit all motorcycles utilizing full wrap OEM or aftermarket hand guards.



All OBR ADV Gear Grip Mitts utilize an adjustable Velcro attachment system and a double button snap option to aid in finding the correct angle of the Velcro straps. Proper adjustment and engagement of the Velcro straps will ensure a secure fitment to your motorcycle.

Thank you for your purchase Let's get started!

1) Invert the Grip Mitt so that the inside Velcro strap is visible. The inside Velcro strap is intended to secure the outboard side of the Grip Mitt to the outside of the hand guard rail. Loop the Velcro around the outside rail of the hand guard.



2) Now fold/re-invert the Grip Mitt inward and over the hand guard and grip. Select which button snap position allows for the best angle of the Velcro strap. Overlap the lower and upper Velcro strap to secure the Grip Mitt around the handlebar.



Make sure that the Grip Mitt and/or Velcro straps do not interfere with any of the motorcycle hand controls.



OBR ADV Gear